

**Quick and Reliable Method for Cleanup of all 209  
PCBs in One Fraction in Environmental Samples**

Tom Hall and Ruud Addink  
Fluid Management Systems  
Billerica MA USA



# Introduction (1)

- **POPs (PCDD/Fs, PCBs) continue to attract interest around the world due to strict regulations enforced in many countries**
- **Rapid and quality sample clean up and analysis is needed for many laboratories processing samples**
- **Processing times and cost are important considerations**
- **In the US, EPA methods SW-846, 1613B, 1668C and 8082A are used for PCBs and PCDD/Fs work**

# Introduction (2)

- **Sample extracts in DCM, hexane or toluene**
- **Cleanup for analysis of all 209 PCBs in common in North America - extracts are often in toluene after Soxhlet Extraction**



# Challenges of POPs Sample Prep

- Labor intensive, prone to error
- Compliance with regulatory procedures and accreditation (lengthy method validation)
- Strict QA/QC requirements
- Sample matrix complexity
- Native background and interferences (can be orders of magnitude higher than analytes)
- Pico/femto-gram analyses require ultra pure extract and excellent instrument sensitivity

## Automated Sample Prep

- **Advantages of Automated Sample Prep**
  - Rapid Turn Around Time: 30 to 45 Minutes for 6 Samples
  - Cleaner Background Interferences: Closed Loop System
  - Quality Results: Certified Pre-packaged Columns
  - Green Technology: Lower solvent and power use
  - QA/QC & Accreditation Requirements: Easier to Manage
  - Computerized Method: Instrumentation based prep

# Manual Sample Prep

- **Advantages of Manual Sample Prep**
  - Most labs use a Manual Methods for the following reasons:
    - No electronics or mechanical components to fail
    - No down time due to the system failure
    - No service contract
    - No capital equipment cost





# Semi-Automated System

## Specification:

- Simple to run, no computerized instrumentation
- Fast: 30 to 45 min
- Closed loop system to give a clean background, low level detection
- Use certified pre-packaged columns
- Green technology, only vacuum pump uses power
- Low solvents, as low as 160 mL for serum
- Economical column kits, choice of low fat and high fat column kits
- No capital equipment cost
- No electronics or mechanical equipment to fail
- No downtime




# Characteristics of Semi-Automated System (EZPrep)






# Columns (1)




# Columns (2)


Classical  
Kit




Classical Plus  
Kit




Mini Kit




High Capacity  
Kit




XL Capacity  
Kit




# Stage 1 Manifold




## Stage 2 Manifold




# Stage 1: to waste



# EZPrep Stage 1




## Stage 2: collect





# EZPrep Stage 2 Fractions





# Attributes

- **Closed loop system:**
  - **Eliminates background contaminants**
  - **No washing needed.**
  - **Capped solvent reservoirs**
- **Optimized for solvent reduction while obtaining highest possible recoveries**
- **Easy sample loading on top of silica column via injection or syringe vial**
- **Columns connect easy with SNAP connections**



## Extracts in hexane - PCBs

- **Stage 1: Connect High Capacity Acid Silica and Alumina (no Carbon) and condition with 60 mL of hexane (vacuum, waste)**
- **Stage 2: Load sample (in hexane, collect Fraction # 1), rinse loading vials with hexane, elute with 160 mL hexane (collect Fraction # 1), remove acid silica, elute alumina with 50 mL dichloromethane (collect Fraction # 1)**
- **All 209 PCBs are now in Fraction # 1**

# SuperVap 6 Concentrator 250 mLs



# SuperVap Concentration/Evaporation

- **System pre-heated to 50 °C.**
- **Samples evaporated at stable T under 8 psi nitrogen.**
- **1 mL extract vial transferred to GC vial (can have direct-to-vial feature).**
- **Recovery standards added (nonane/dodecane).**
- **Extract taken to 10 uL volume with a gentle stream of nitrogen at ambient temperature.**



# SuperVap 24 position GC vial Concentrator



# Direct-to-Vial




GC vial

# 7010B TripleQuad



# Native PCBs in Soil extract





# Column Kits with various fat removal capacities for samples in hexane


		STAGE 1	STAGE 2			
						PCBs
	Fat Removal	Hexane	Hexane	Hexane		DCM
Column kits	Capacity	conditioning	sample volume	Elute Silica		Alumina
Mini kit	0.15 Gram	20	10	80		50
Classical kit	0.5 g	20	10	90		50
Classical Plus	1.0 g	20	10	100		50
High Capacity	2.5 g	40	30	160		50
Extra high Capacity	5.0 g	60	30	180		50

# Extracts in toluene -PCBs

- Stage 1: Connect High-Capacity Acid Silica and Alumina (no Carbon) and condition with 60 mL of hexane (vacuum, waste)
- Stage 2: Load sample (in 2-10 mL toluene, collect Fraction # 1), rinse loading vials with hexane, elute with 60 mL hexane (collect Fraction # 1), remove acid silica, elute alumina with 50 mL dichloromethane (collect Fraction # 1)
- All 209 PCBs are now in Fraction # 1




## 13C recoveries PCBs soil



10 g soil in  
toluene, n=6

# $^{13}\text{C}$ recoveries PCBs salmon




2 g salmon in  
toluene, n=6

# Conclusions (1)

- **Samples in toluene (environmental, food): 2-10 mL toluene, collect all 209 PCBs in one fraction using hexane and DCM**
- **Reduced hexane volume needed for acid silica column because of presence toluene (can also be DCM)**
- **Alternative for samples in toluene: use hexane to have 209 PCBs in one fraction**
- **Works also for samples in hexane but more hexane needed in that case for silica elution ("toluene effect" not present)**



## Conclusions (2)

- **High sample throughput → 18 samples/hour**
    - **6 samples in parallel per station**
    - **3 stations fit in one hood**
  - **System gives excellent recoveries for PCBs comparable to automated systems**
  - **Use of certified pre-packaged columns guarantees low native background**
  - **No worries about breakdown or downtime**
  - **No washing needed**
  - **No cross-contamination**
  - **Low cost**
- 

Come see us at booth G-2

Questions?

[raddink@fms-inc.com](mailto:raddink@fms-inc.com)

[thall@fms-inc.com](mailto:thall@fms-inc.com)